

Rockchip USB FFS Test Demo 使用说明

文件标识：RK-KF-YF-464

发布版本：V1.2.2

日期：2022-05-26

文件密级：☐绝密 ☐秘密 ☐内部资料 ☒公开

免责声明

本文档按“现状”提供，福州瑞芯微电子股份有限公司（“本公司”，下同）不对本文档的任何陈述、信息和内容的准确性、可靠性、完整性、适销性、特定目的性和非侵权性提供任何明示或暗示的声明或保证。本文档仅作为使用指导的参考。

由于产品版本升级或其他原因，本文档将可能在未经任何通知的情况下，不定期进行更新或修改。

商标声明

“Rockchip”、“瑞芯微”、“瑞芯”均为本公司的注册商标，归本公司所有。

本文档可能提及的其他所有注册商标或商标，由其各自拥有者所有。

版权所有 © 2022 福州瑞芯微电子股份有限公司

超越合理使用范畴，非经本公司书面许可，任何单位和个人不得擅自摘抄、复制本文档内容的部分或全部，并不得以任何形式传播。

福州瑞芯微电子股份有限公司

Fuzhou Rockchip Electronics Co., Ltd.

地址：福建省福州市铜盘路软件园A区18号

网址：www.rock-chips.com

客户服务电话：+86-4007-700-590

客户服务传真：+86-591-83951833

客户服务邮箱：fae@rock-chips.com

前言

概述

本文档提供 Rockchip 平台 USB FFS Test Demo 的使用方法。

产品版本

芯片名称	内核版本
RK3399、RK3368、RK3366、RK3328、RK3288、RK312X、RK3188、RK30XX、RK3308、RK3326、PX30	Linux-4.4、Linux-4.19

读者对象

本文档（本指南）主要适用于以下工程师：

软件工程师

技术支持工程师

修订记录

日期	版本	作者	修改说明
2018-07-02	V1.0	吴良峰	初始版本
2019-01-09	V1.1	吴良峰	使用 markdownlint 修订格式
2019-11-11	V1.2	吴良峰	修改文档名称，支持Linux-4.19
2020-02-19	V1.2.1	吴良峰	增加免责声明，商标声明以及版权声明
2022-05-26	V1.2.2	吴良峰	修改文件标识和文档规范

目录

Rockchip USB FFS Test Demo 使用说明

1. 测试 Demo 源码
2. Toolchain 下载地址 (ARCH=arm64)
3. Libaio 下载地址
4. Libaio 库的编译
5. 测试 Demo 的编译
 - 5.1 Device_app 的编译
 - 5.2 Host_app 的编译
6. 测试方法
7. 测试 Demo USB 3.0 的支持

1. 测试 Demo 源码

1. Simple-Demo: kernel/tools/usb/ffs-aio-example/simple
2. Multibuf-Demo: kernel/tools/usb/ffs-aio-example/multibuff

Note:

- The two test demo showing usage of Asynchronous I/O API of FunctionFS.
- "Simple-Demo" is a simple example of bidirectional data; "Multibuf-Demo" shows multi-buffer data transfer, which may to be used in high performance applications.
- Both examples contains userspace applications for device and for host.
- It needs libaio library on the device, and libusb library on host.
- Only support USB2.0

2. Toolchain 下载地址（ARCH=arm64）

```
ssh://wulf@10.10.10.29:29418/rk/prebuilts/gcc-linaro-6.3.1-2017.05-x86_64_aarch64-linux-gnu
```

Note: "wulf"请修改为自己的 Gerrit 用户名

3. Libaio 下载地址

<https://pagure.io/libaio.git>

4. Libaio 库的编译

进入 libaio/src 目录下，修改 Makefile 的“CC”和“AR”

```
diff --git a/src/Makefile b/src/Makefile
index eadb336..9d3f19b 100644
--- a/src/Makefile
+++ b/src/Makefile
@@ -1,3 +1,5 @@
+CC = $(CROSS_COMPILE)gcc
+AR = $(CROSS_COMPILE)ar
prefix=/usr
includedir=$(prefix)/include
libdir=$(prefix)/lib
```

然后，执行 make 命令

```
make ARCH=arm64 CROSS_COMPILE=../../toolchain/gcc-linaro-6.3.1-2017.05-  
x86_64_aarch64-linux-gnu/bin/aarch64-linux-gnu-
```

生成静态库: libaio.a

生成动态库: libaio.so.1.0.1

建议使用静态库 libaio.a 来编译 FFS 测试 Demo

5. 测试 Demo 的编译

5.1 Device_app 的编译

1. 将 libaio/src/libaio.h 拷贝到 kernel/tools/include/tools/.
2. 将静态库 libaio.a 分别拷贝到 kernel/tools/usb/ffs-aio-example/multibuff/device_app/. 和 kernel/tools/usb/ffs-aio-example/simple/device_app/.
3. 修改 aio_multibuff.c 和 aio_simple.c 的头文件

```
diff --git a/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c  
b/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c  
index aaca1f4..e0bf98c 100644  
--- a/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c  
+++ b/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c  
@@ -42,7 +42,7 @@  
#include <stdbool.h>  
#include <sys/eventfd.h>  
  
-#include "libaio.h"  
+#include <tools/libaio.h>  
#define IOCB_FLAG_RESFD (1 << 0)  
  
#include <linux/usb/functionfs.h>  
diff --git a/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c  
b/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c  
index 1f44a29..3dab7f1 100644  
--- a/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c  
+++ b/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c  
@@ -42,7 +42,7 @@  
#include <stdbool.h>  
#include <sys/eventfd.h>  
  
-#include "libaio.h"  
+#include <tools/libaio.h>  
#define IOCB_FLAG_RESFD (1 << 0)  
  
#include <linux/usb/functionfs.h>
```

4. 增加 Makefile 文件（指定在当前目录下，查找静态库 libaio.a 文件）

```
kernel/tools/usb/ffs-aio-example/simple/device_app/Makefile
```

```
# Makefile for USB tools
CC = $(CROSS_COMPILE)gcc
AIO_LIBS = -L. -laio
WARNINGS = -Wall -Wextra
CFLAGS = $(WARNINGS) -static -I../../../../../../include
LDFLAGS = $(AIO_LIBS)

all: aio_simple
%: %.c
    $(CC) $(CFLAGS) -o $@ $^ $(LDFLAGS)

clean:
    $(RM) aio_simple
```

```
kernel/tools/usb/ffs-aio-example/multibuff/device_app/Makefile
```

```
# Makefile for USB tools
CC = $(CROSS_COMPILE)gcc
AIO_LIBS = -L. -laio
WARNINGS = -Wall -Wextra
CFLAGS = $(WARNINGS) -static -I../../../../../../include
LDFLAGS = $(AIO_LIBS)

all: aio_multibuff
%: %.c
    $(CC) $(CFLAGS) -o $@ $^ $(LDFLAGS)

clean:
    $(RM) aio_multibuff
```

5. 执行 make 命令

```
make ARCH=arm64 CROSS_COMPILE=../../../../../../toolchain/gcc-linaro-6.3.1-2017.05-x86_64_aarch64-linux-gnu/bin/aarch64-linux-gnu-
```

在 ffs-aio-example/simple/device_app 和 ffs-aio-example/multibuff/device_app 目录下，分别执行上述的 make 命令，编译成功后，得到 ARM64 平台的可执行文件“aio_simple”和“aio_multibuff”。

5.2 Host_app 的编译

Host_app 可以运行于 PC Ubuntu，编译时不需要对源码做任何改动，只要在 kernel/tools/usb/ffs-aio-example/simple/host_app 和 kernel/tools/usb/ffs-aio-example/multibuff/host_app 目录下执行 make 命令即可，得到可执行文件“test”。

6. 测试方法

1. 将编译 Demo Device-app 得到的可执行文件 “aio_simple” 和 “aio_multibuff” 拷贝到测试平台的 /data/ 路径下，
并设置可执行的权限。
2. 断开测试平台 USB 与 PC 的连接。
3. 配置 Configfs 和 Function FS Gadget

1.1 通用的配置方法

如果是使用 RK Android 平台，配置方法请参考“1.2 基于 RK3399 Android 挖掘机平台的配置方法”。

```
#usb init参考android 脚本 init.rk30board.usb.rc和init.usb.configfs.rc

#Manual / Command line instructions :
#Mount ConfigFS and create Gadget
mount -t configfs none /config
mkdir /config/usb_gadget/g1

#Set default Vendor and Product IDs and so on for now
echo 0x1d6b > /config/usb_gadget/g1/idVendor
echo 0x0105 > /config/usb_gadget/g1/idProduct
echo 0x0310 > /config/usb_gadget/g1/bcdDevice
echo 0x0200 > /config/usb_gadget/g1/bcdUSB

#Create English strings and add random deviceID
mkdir /config/usb_gadget/g1/strings/0x409
echo 0123459876 > /config/usb_gadget/g1/strings/0x409/serialnumber

#Update following if you want to
echo "rockchip" > /config/usb_gadget/g1/strings/0x409/manufacturer
echo "rkusbtest" > /config/usb_gadget/g1/strings/0x409/product

#Create gadget configuration
mkdir /config/usb_gadget/g1/configs/b.1
mkdir /config/usb_gadget/g1/configs/b.1/strings/0x409
echo "test" > /config/usb_gadget/g1/configs/b.1/strings/0x409/configuration
echo 500 > /config/usb_gadget/g1/configs/b.1/MaxPower

#Set os_desc and link it to the gadget configuration
echo 0x1 > /config/usb_gadget/g1/os_desc/b_vendor_code
echo "MSFT100" > /config/usb_gadget/g1/os_desc/qw_sign
ln -s /config/usb_gadget/g1/configs/b.1 /config/usb_gadget/g1/os_desc/b.1

#Create test FunctionFS function
#And link it to the gadget configuration
mkdir /config/usb_gadget/g1/functions/ffs.test
rm /config/usb_gadget/g1/configs/b.1/f1
ln -s /config/usb_gadget/g1/functions/ffs.test
/config/usb_gadget/g1/configs/b.1/f1

#Create ffs test and mount it, then /dev/usb-ffs/test/ep0 will be created
mkdir -p /dev/usb-ffs/test
mount -o rmode=0770,fmode=0660,uid=1024,gid=1024 -t functionfs test /dev/usb-ffs/test
```

1.2 基于 RK3399 Android 挖掘机平台的配置方法

如果是基于 RK3399 Android 挖掘机平台进行测试，由于 Android 的 usb init 文件已经创建的 Configfs，并完成了部分 Configfs 的配置工作，所以只需要再执行如下的配置步骤：

```
#usb init参考android 脚本 init.rk30board.usb.rc和init.usb.configfs.rc

#Manual / Command line instructions :

#Set default Vendor and Product IDs and so on for now
echo 0x1d6b > /config/usb_gadget/g1/idVendor
echo 0x0105 > /config/usb_gadget/g1/idProduct

#Set gadget configuration
echo "test" > /config/usb_gadget/g1/configs/b.1/strings/0x409/configuration

#Create test FunctionFS function
#And link it to the gadget configuration
mkdir /config/usb_gadget/g1/functions/ffs.test
rm /config/usb_gadget/g1/configs/b.1/f1
ln -s /config/usb_gadget/g1/functions/ffs.test
/config/usb_gadget/g1/configs/b.1/f1

#Create ffs test and mount it, then /dev/usb-ffs/test/ep0 will be created
mkdir -p /dev/usb-ffs/test
mount -o rmode=0770,fmode=0660,uid=1024,gid=1024 -t functionfs test /dev/usb-ffs/test
```

4. 执行测试平台的可执行文件“aio_simple”或“aio_multibuff”

```
./aio_simple /dev/usb-ffs/test &
```

```
./aio_multibuff /dev/usb-ffs/test &
```

如果执行成功，可以在 /dev/usb-ffs/test 目录下，查看到 ep0/ep1/ep2 三个设备端点。

5. 使能 USB 控制器

```
echo fe800000.dwc3 >/config/usb_gadget/g1/UDC
```

6. 连接 USB 到 PC ubuntu 的 USB 接口，然后执行 lsusb，查看是否有 USB 设备“1d6b:0105 Linux Foundation FunctionFS Gadget”，如果存在，则表明 USB FFS Gadget 枚举成功。

7. 在 PC ubuntu 上，执行 host 端的测试 app“test”，则会通过 libusb 主动搜索 ID 为“1d6b:0105”的 USB 设备，并进行 USB 传输测试。

7. 测试 Demo USB 3.0 的支持

Kernel tools 源码提供的 USB FFS 测试 Demo 最高只能支持 USB 2.0，不能支持 USB 3.0，如果要支持 USB 3.0，需要更新如下的补丁，测试方法与 USB 2.0 一样。

```
diff --git a/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c
b/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c
index aaca1f4..e0bf98c 100644
--- a/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c
```



```

+++ b/tools/usb/ffs-aio-example/multibuff/device_app/aio_multibuff.c
@@ -57,16 +57,30 @@ static const struct {
    struct usb_functionfs_descs_head_v2 header;
    __le32 fs_count;
    __le32 hs_count;
+   __le32 ss_count;
+   __le32 os_count;
    struct {
        struct usb_interface_descriptor intf;
        struct usb_endpoint_descriptor_no_audio bulk_sink;
        struct usb_endpoint_descriptor_no_audio bulk_source;
    } __attribute__((packed)) fs_descs, hs_descs;
+   struct {
+       struct usb_interface_descriptor intf;
+       struct usb_endpoint_descriptor_no_audio sink;
+       struct usb_ss_ep_comp_descriptor sink_comp;
+       struct usb_endpoint_descriptor_no_audio source;
+       struct usb_ss_ep_comp_descriptor source_comp;
+   } __attribute__((packed)) ss_descs;
+   struct usb_os_desc_header os_header;
+   struct usb_ext_compat_desc os_desc;
+
    } __attribute__((packed)) descriptors = {
        .header = {
            .magic = htole32(FUNCTIONFS_DESCRIPTOR_MAGIC_V2),
            .flags = htole32(FUNCTIONFS_HAS_FS_DESC |
-                           FUNCTIONFS_HAS_HS_DESC),
+                           FUNCTIONFS_HAS_HS_DESC |
+                           FUNCTIONFS_HAS_SS_DESC |
+                           FUNCTIONFS_HAS_MS_OS_DESC),
            .length = htole32(sizeof(descriptors)),
        },
        .fs_count = htole32(3),
@@ -115,6 +129,57 @@ static const struct {
        .wMaxPacketSize = htole16(512),
    },
    },
+   .ss_count = htole32(5),
+   .ss_descs = {
+       .intf = {
+           .bLength = sizeof(descriptors.ss_descs.intf),
+           .bDescriptorType = USB_DT_INTERFACE,
+           .bInterfaceNumber = 0,
+           .bNumEndpoints = 2,
+           .bInterfaceClass = USB_CLASS_VENDOR_SPEC,
+           .iInterface = 1,
+       },
+       .sink = {
+           .bLength = sizeof(descriptors.ss_descs.sink),
+           .bDescriptorType = USB_DT_ENDPOINT,
+           .bEndpointAddress = 1 | USB_DIR_IN,
+           .bmAttributes = USB_ENDPOINT_XFER_BULK,
+           .wMaxPacketSize = htole16(1024),
+       },
+       .sink_comp = {

```

```

+         .bLength = sizeof(descriptors.ss_descs.sink_comp),
+         .bDescriptorType = USB_DT_SS_ENDPOINT_COMP,
+         .bMaxBurst = 4,
+     },
+     .source = {
+         .bLength = sizeof(descriptors.ss_descs.source),
+         .bDescriptorType = USB_DT_ENDPOINT,
+         .bEndpointAddress = 2 | USB_DIR_OUT,
+         .bmAttributes = USB_ENDPOINT_XFER_BULK,
+         .wMaxPacketSize = htole16(1024),
+     },
+     .source_comp = {
+         .bLength = sizeof(descriptors.ss_descs.source_comp),
+         .bDescriptorType = USB_DT_SS_ENDPOINT_COMP,
+         .bMaxBurst = 4,
+     },
+ },
+ .os_count = htole32(1),
+ .os_header = {
+     .interface = htole32(1),
+     .dwLength = htole32(sizeof(descriptors.os_header) +
sizeof(descriptors.os_desc)),
+     .bcdVersion = htole32(1),
+     .wIndex = htole32(4),
+     .bCount = htole32(1),
+     .Reserved = htole32(0),
+ },
+ .os_desc = {
+     .bFirstInterfaceNumber = 0,
+     .Reserved1 = htole32(1),
+     .CompatibleID = {0},
+     .SubCompatibleID = {0},
+     .Reserved2 = {0},
+ },
+ },
+ };

```

```

#define STR_INTERFACE "AIO Test"

```

```

diff --git a/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c

```

```

b/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c

```

```

index 1f44a29..3dab7f1 100644

```

```

--- a/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c

```

```

+++ b/tools/usb/ffs-aio-example/simple/device_app/aio_simple.c

```

```

@@ -55,16 +55,30 @@ static const struct {
     struct usb_functionfs_descs_head_v2 header;
     __le32 fs_count;
     __le32 hs_count;
+
+     __le32 ss_count;
+     __le32 os_count;
     struct {
         struct usb_interface_descriptor intf;
         struct usb_endpoint_descriptor_no_audio bulk_sink;
         struct usb_endpoint_descriptor_no_audio bulk_source;
     } __attribute__((packed)) fs_descs, hs_descs;
+
+     struct {
+         struct usb_interface_descriptor intf;

```

```

+         struct usb_endpoint_descriptor_no_audio sink;
+         struct usb_ss_ep_comp_descriptor sink_comp;
+         struct usb_endpoint_descriptor_no_audio source;
+         struct usb_ss_ep_comp_descriptor source_comp;
+     } __attribute__((packed)) ss_descs;
+     struct usb_os_desc_header os_header;
+     struct usb_ext_compat_desc os_desc;
+
+ } __attribute__((packed)) descriptors = {
+     .header = {
+         .magic = htobe32(FUNCTIONFS_DESCRIPTOR_MAGIC_V2),
+         .flags = htobe32(FUNCTIONFS_HAS_FS_DESC |
-             FUNCTIONFS_HAS_HS_DESC),
+             FUNCTIONFS_HAS_HS_DESC |
+             FUNCTIONFS_HAS_SS_DESC |
+             FUNCTIONFS_HAS_MS_OS_DESC),
+         .length = htobe32(sizeof(descriptors)),
+     },
+     .fs_count = htobe32(3),
@@ -113,6 +127,57 @@ static const struct {
+         .wMaxPacketSize = htobe16(512),
+     },
+ },
+ .ss_count = htobe32(5),
+ .ss_descs = {
+     .intf = {
+         .bLength = sizeof(descriptors.ss_descs.intf),
+         .bDescriptorType = USB_DT_INTERFACE,
+         .bInterfaceNumber = 0,
+         .bNumEndpoints = 2,
+         .bInterfaceClass = USB_CLASS_VENDOR_SPEC,
+         .iInterface = 1,
+     },
+     .sink = {
+         .bLength = sizeof(descriptors.ss_descs.sink),
+         .bDescriptorType = USB_DT_ENDPOINT,
+         .bEndpointAddress = 1 | USB_DIR_IN,
+         .bmAttributes = USB_ENDPOINT_XFER_BULK,
+         .wMaxPacketSize = htobe16(1024),
+     },
+     .sink_comp = {
+         .bLength = sizeof(descriptors.ss_descs.sink_comp),
+         .bDescriptorType = USB_DT_SS_ENDPOINT_COMP,
+         .bMaxBurst = 4,
+     },
+     .source = {
+         .bLength = sizeof(descriptors.ss_descs.source),
+         .bDescriptorType = USB_DT_ENDPOINT,
+         .bEndpointAddress = 2 | USB_DIR_OUT,
+         .bmAttributes = USB_ENDPOINT_XFER_BULK,
+         .wMaxPacketSize = htobe16(1024),
+     },
+     .source_comp = {
+         .bLength = sizeof(descriptors.ss_descs.source_comp),
+         .bDescriptorType = USB_DT_SS_ENDPOINT_COMP,

```

```

+             .bMaxBurst = 4,
+             },
+         },
+         .os_count = htogle32(1),
+         .os_header = {
+             .interface = htogle32(1),
+             .dwLength = htogle32(sizeof(descriptors.os_header) +
sizeof(descriptors.os_desc)),
+             .bcdVersion = htogle32(1),
+             .wIndex = htogle32(4),
+             .bCount = htogle32(1),
+             .Reserved = htogle32(0),
+         },
+         .os_desc = {
+             .bFirstInterfaceNumber = 0,
+             .Reserved1 = htogle32(1),
+             .CompatibleID = {0},
+             .SubCompatibleID = {0},
+             .Reserved2 = {0},
+         },
+     };

#define STR_INTERFACE "AIO Test"

```